

Resumen Papers

DAMAVA

20 de junio de 2017

1. Medidores de Desempeño

TP	Casos de mastitis subclínica correctamente clasificados
FP	Casos sanos clasificados erróneamente.
FN	Casos de mastitis subclínica clasificados erróneamente.
TN	Casos sanos correctamente clasificados.

Cuadro 1: Clasificación de resultados

$$Sensibilidad = \frac{TP}{TP + FN} \quad Especificidad = \frac{TN}{TN + FP} \quad Error = \frac{FP}{FP + TP}$$

2. [1]

2.1. Métodos para el tratamiento de la serie temporal

- Media movil:

$$Y'_t = \frac{1}{N} \sum_{k=1}^N Y_{t-k} \quad N = 10$$

- Media movil exponencial con peso:

$$Y'_t = \alpha Y_{t-1} + (1 - \alpha) Y'_{t-1}$$

Cuanto mayor el valor de α , mayor es el peso de los últimos valores. Se testearon los siguientes valores de $\alpha = \{0,2; 0,4; 0,6; 0,8\}$

- Regresión local con peso




Figura 1: Ejemplo de ajuste de polinomio.

2.2. Resultados

Treat+	Threshold	Block-sensitivity	Specificity	Error rate	TP cows/day	FP cows/day
100						
MA	7%	84.7	73.0	56.2	12.3	15.7
EWMA	7%	83.6	73.4	56.0	12.2	15.5
LOESS	5%	87.9	66.6	60.4	12.8	19.5
Treat+	Threshold	Block-sensitivity	Specificity	Error rate	TP cows/day	FP cows/day
400						
MA	9%	86.1	81.4	83.3	3	15.1
EWMA	9%	85.0	81.6	83.2	3	15.0
LOESS	6%	85.0	74.5	87.4	3	20.8

Figura 2: Resultados para el umbral óptimo.

3. [2]

Existen los siguientes sistemas de detección de mastitis:

- Lactate




Figura 3: Una vaca que tuvo una infección la cual se curó sola(?) (self-cured) después de un periodo de 18 días.

- **SCC** En la figura 4 se observan los resultados de un direct online SCC sensor.

Table 1 Summary of SCC sensor prototype performance: time-to-drain thresholds, the total number of milk samples (n), and the number of correct (n_{correct}) and proportion of correct (p) measurements from the calibration and on-line testing.

SCC band (kcells/ml)	Time-to-drain thresholds (s)	n (lab)	n_{correct} (p) (lab)	n (on-line)	n_{correct} (p) (on-line)
<200	<1.1	38	36 (95%)	64	62 (97%)
200 – 500	1.1 – 1.7	39	33 (85%)	2	2 (100%)
500 – 1500	1.7 – 6.2	59	45 (76%)	2	1 (50%)
1500 – 5000	6.2 – 59	60	43 (72%)	0	0 N/A
>5000	>59 ¹	42	40 (95%)	1	1 (100%)
Overall	N/A	238	197 (83%)	69	66 (96%)

Figura 4

- **Conductividad del cuarto**

4. [3]

4.1. CE

ver [4]

4.2. Mediciones de sangre online

Blood in milk is a very good indicator of udder injury, including mastitis, and milk should be diverted from the milk line.

4.3. Online Somatic Cell Count

DeLaval has launched an online Somatic Cell Counter for the DeLaval VMS.

4.4. Combined mastitis indices

Steenevold et al. (5) investigated the combined use of electrical conductivity and on-line measurements of somatic cell counts. The addition of somatic cell count data moved the success rate of mastitis detection to 32 %, but moved the specificity to 98.8 %.

4.5. Measurement and interpretation of Lactate Dehydrogenase

5. [4]

5.1. Introduction




Figura 5




Figura 6




Figura 7

5.2. Results

5.2.1. Level and Variation of EC measurements

Electrical conductivity results obtained at the quarter level are given in 8.

Table 1. Distributions of electrical conductivity values (means \pm standard errors) for healthy, subclinically and clinically infected quarters.			
	Healthy	Subclinical	Clinical
no.	10,431	2122	599
X_{20}^1	$4.87^a \pm 0.01$	$5.37^b \pm 0.02$	$6.44^c \pm 1.53$
σ_{EC}^2	$0.125^a \pm 0.004$	$0.217^b \pm 0.008$	$0.758^c \pm 0.013$
^{a,b,c} Means or variances in the same row with different subscripts differ significantly ($P < 0.001$). ¹ X_{20} = Average of the 20 highest electrical conductivity quarter values within milking. ² σ_{EC}^2 = Variation in electrical conductivity registrations for a quarter within milking.			

Figura 8

At cow level, all EC traits were higher for the infected cows compared with healthy cows (9).

Table 2. Distributions of electrical conductivity traits (means \pm standard errors) for healthy, subclinically infected, and clinically infected cows.			
	Healthy	Subclinical	Clinical
no.	1353	778	340
Max_ X_{20}^1	$5.30^a \pm 0.03$	$5.75^b \pm 0.04$	$6.73^c \pm 0.06$
Max_ σ_{EC}^2	$0.242^a \pm 0.015$	$0.332^b \pm 0.020$	$0.818^c \pm 0.030$
IQR_ X_{20}^3	$1.124^a \pm 0.004$	$1.182^b \pm 0.006$	$1.369^c \pm 0.009$
IQR_ σ_{EC}^2	$6.85^a \pm 0.52$	$7.72^b \pm 0.68$	$16.93^c \pm 1.03$
^{a,b,c} Means in the same row with different subscript differ significantly ($P < 0.001$). ¹ Max_ X_{20} = maximum quarter X_{20} value (average of the 20 highest electrical conductivity quarter values within milking) within cow and milking. ² Max_ σ_{EC}^2 = maximum quarter σ_{EC}^2 value (the variation in electrical conductivity registrations for a quarter within milking) within cow and milking. ³ IQR_ X_{20} = inter-quarter ratio between maximum and minimum quarter X_{20} value within cow and milking. ⁴ IQR_ σ_{EC}^2 = inter-quarter ratio between the maximum and minimum quarter σ_{EC}^2 within cow and milking.			

Figura 9

5.2.2. Classification of cows according to health status




Figure 10

Results from the discriminant function analyses are given in 11.

Table 3. Sensitivities and specificities for separation of healthy and infected cows by use of different EC traits; calculated for Subset 1 (healthy and clinically infected cows), Subset 2 (healthy and subclinically infected cows), Subset 3 (healthy and clinically + subclinically infected cows), and the full data set (healthy, clinically infected, and subclinically infected cows).

EC trait ¹	Subset 1		Subset 2		Subset 3		Full data set		
	Sensitivity	Specificity	Sensitivity	Specificity	Sensitivity	Specificity	Sensitivity clinical	Sensitivity subclinical	Specificity
Max_X ₂₀	17.9	91.5	15.8	91.5	41.8	79.8	30.6	1.9	93.6
Max_σ ² _{EC}	16.2	98.0	2.8	98.0	21.0	91.7	17.4	0	97.4
IQR_X ₂₀	46.2	92.3	15.9	92.3	41.4	85.5	45.0	1.9	94.3
IQR_σ ² _{EC}	32.1	97.0	3.6	97.0	34.7	79.6	18.5	0	96.2
Combination	47.9	91.9	19.4	91.9	44.8	84.6	43.5	7.8	92.9

¹Max_X₂₀ = maximum quarter X₂₀ value (average of the 20 highest electrical conductivity quarter values within milking) within cow and milking, Max_σ²_{EC} = maximum quarter σ²_{EC} value (the variation in electrical conductivity registrations for a quarter within milking) within cow and milking, IQR_X₂₀ = inter-quarter ratio between maximum and minimum quarter X₂₀ value within cow and milking, and IQR_σ²_{EC} = inter-quarter ratio between the maximum and minimum quarter σ²_{EC} within cow and milking. Combination is combination of all 4 electrical conductivity traits.

Figure 11

6. [5]

6.1. Results

6.1.1. Level I: Sensor technique

- CE((15)
- CE y milk colour sensors (7)
- Biosensor para detectar enzimas haptoglobine, L-lactate (5)
- SCC sensor (2)

6.1.2. System quality

The reported sensitivities ranged from 55 per cent to 89 per cent, while reported specificities ranged from 56 per cent to 99 per cent. For the sensor systems studied, a trade-off exists between sensitivity and specificity as high sensitivity (\approx 80) vice versa. None of the studies reported a combination of high sensitivity and high specificity. Moreover, none of the studies met the **ISO/FDIS 20966 limit of 80 per cent sensitivity with 99 per cent specificity**.

For EC, in combination with milk colour sensors, good performance has been reported (84.6 per cent sensitivity and 99.4 per cent specificity) [1], with treated CM cases as a gold standard.

The Herd Navigator® (DeLaval, Tumba, Sweden), which automatically takes and analyses milk samples, seems to perform good (80–82 per cent sensitivity and 98 per cent specificity) [2,3], although this is only based on two non- peer-reviewed studies published in conference proceedings and the used gold standard is unclear.

Referencias

- [1] D. CAVERO, K.-H. TOLLE, G. RAVE, C. BUXADÉ, J. KRIETER, " *Analysing serial data for mastitis detection by means of local regression*".
- [2] D.S. WHYTE, P.T. JOHNSTONE, R.W. CLAYCOMB AND G.A. MEIN, " *Online sensors for earlier, more reliable mastitis detection*".
- [3] JENS YDE LOM, " *Sensors for mastitis management*".
- [4] E. NORBERG, H. HOGEVEEN, I.R. KORSGAARD, N.C. FRIGGENS, K.H.M.N. SLOTH & P. LOVENDAHL, " *Electrical Conductivity of Milk: Ability to predict Mastitis Status*".
- [5] C.J. RUTTEN, A.G.J. VELTHUIS, W. STEENEVELD AND H. HOGEVEEN, " *CAN SENSOR TECHNOLOGY BENEFIT MASTITIS CONTROL*".

¹Song X, van der Tol R. Automatic Detection of Clinical Mastitis in Astronaut A3TM Milking Robot; 2010; Toronto, Canada. pp. 154-155.

²Mazeris F. DeLaval Herd Navigator(R) Proactive Herd Management; 2010; Toronto, Canada. pp. 26-27.

³Vreeburg N. Precision Management On Two Dutch Dairy Farms By Use of Herd Navigator (R); 2010; Toronto, Canada. pp. 104-105.